

Product SPOTLIGHT

Keep out debris that can damage or destroy pumps



Operator designed



Water passes through — but wipes and rags don't!

USABlueBook
EXCLUSIVE

FlowRake Rag Catchers

NEW!

- Catches flushables before they become problems
- Compact — fits in small lift stations and basins

Protect your lift station pumps from damaging flushables with the operator-designed FlowRake rag catcher. It mounts on the pipe stub in your lift station, where it captures and retains flushables as they flow out of the pipe.

FlowRake is easily maintained from above ground—no need to enter the lift station or basin. Simply lift the FlowRake from its position on the pipe, discard the debris and put the FlowRake back on the pipe. An optional hook and extension pole are listed below, or a fish gaff works great! FlowRake features welded stainless steel one-piece construction that will outlast the pumps it protects.

FITS PIPE SIZE	RAKE DIMENSIONS (L x W)	STOCK #	EACH
4"	10" x 8"	77832	\$
6"	11" x 10 1/2"	77833	
8"	13" x 12 1/2"	77834	

Accessories

DESCRIPTION	STOCK #	EACH
Retrieval Hook	27758	\$
Telescoping Pole, 7 to 14'L	23269	

The FlowRake mounts to your pipe stub using the integral locking peg. For proper installation, you need at least 3" of pipe sticking out from the wall. Drill a 3/8" hole into the topside of the pipe (approximately 1 1/2" from the end of the pipe stub). When the locking peg seats into the 3/8" hole, the FlowRake is secured to the pipe.

operator notes

StationGuard Manual Bar Screens

- Save on expensive pump repairs or replacement
- Lightweight for easy retrieval

Designed by an operator, StationGuard is the perfect solution for small pump stations that don't have bar screen protection. It features PVC, ABS and stainless steel construction for maximum corrosion resistance. Mount on the wall or directly onto the waste stream pipe at your plant or inside the lift station.

Two-piece design features a basket with mounting cradle that's easy to maintain once installed. Just use the J-hook and handle (sold separately) to remove, empty and replace basket. Spacings on basket can be adjusted in 1/2" increments depending on the size of the objects you're trying to catch.



FITS PIPE SIZE	BASKET DIMENSIONS	STOCK #	EACH
4"	23"L x 4 1/2"W	38777	\$
6"	23"L x 6 1/2"W	38778	
8"	23"L x 8 1/2"W	38779	
10"	23"L x 10 1/2"W	38780	
12"	44"L x 12 1/2"W	38781	

Accessories

DESCRIPTION	STOCK #	EACH
StationGuard J-Hook	38782	\$
60" Wood Handle w/ Metal Thread For Use with J-Hook	92113	

Let's face it. Who wants to work on a plugged pump in the middle of the night?



Hi, I'm Isaac K.
"Our Sales team is here to help you provide safe water to your community. Let us know how we can assist."